



Important notes:

- * Up to two spacers can be used to load smaller reloads in a motor casing that is one or two sizes larger than the reload.
- * The additional weight per case spacer + extra casing length = 27 grams (54 grams when using 2 spacers)
- * The spacers can be used for all Pro29 casings. An XL spacer is not required. A regular spacer reduces an 6GXL case to a 6G case.

Instructions:

- (1) Drop spacer(s) into motor case with the rounded end towards the rounded end of the motor.
- (2) Install the reload kit as per instructions.
- (3) Verify that the space above the reload kit forward closure is completely occupied by the spacer(s).

REV	DESCRIPTION	DRAWN	CHKD	DATE
REVISIONS				
<small>All changes must be processed and reprinted. Destroy all previous copies.</small>				



**CESARONI
TECHNOLOGY
INCORPORATED**
2561 STOUFFVILLE ROAD GORMLEY ONTARIO CANADA

Unless Otherwise Specified
 X/X ± 1/64
 .XX ± 0.010
 .XXX ± 0.002
 .XXXX ± 0.0005
 X° ± 0°-30°
 BREAK ALL SHARP
 EDGES .01 X 45°
 CHAMFER ALL TAPPED HOLES
 90° TO THREADED DIAMETER

THIS DOCUMENT
CONTAINS
CONFIDENTIAL
PROPRIETARY
INFORMATION.
UNAUTHORIZED USE
OR REPRODUCTION
IS PROHIBITED.

SCALE: 1:1	DATE (DD/MM/YY): 11/01/10
DRAWN BY: A.L.T.	DRAWING SIZE: A
WEIGHT: -	CUSTOMER: -
MATERIAL: Various	SURFACE TREATMENT: -

FILE NAME: Pro29-Case_Spacer1.dwg
TITLE: Pro29 Case Spacer in 2G and 3G Case with 1G Reload
SHEET: 1 OF 1
PROJECT #: 0